


Instructions to use a scanner Bookeye 4

(basic informations)


/ the files that you scanned, you can save only on USB key/

1. Choose „dávkový režim“ – default settings is: scanning both pages, resolution: 200 DPI, quality: 24 bit color, format of files: PDF
2. Place the book in middle of the scanning area to the bottom edge, with the text of the document was in the intersection of the red lines. A horizontal line is used to align the document by text, a vertical line permit the sharing document on left and right sides.


3. Saving the files on the USB key: choose -  insert the USB key and select –




- Select document storage format (multipage PDF or single files)



- It is notified that within one minute all files from the scanner will be deleted.




- If you want continue to scan after you stored the files on the USB disk in the same



batch, select -

- If you want to scan after you stored the files on the USB disk in the new batch, select -



- If you want to stop scanning, select -

